



RTOS Debugger for PikeOS

ARM
PowerPC
x86

- Real Time, non-intrusive Display of PikeOS System Resources
- Debugging PikeOS Kernel, Tasks and Threads
- Debugging Elinos and POSIX personalities
- Full Integrated MMU Support
- SMP Support
- Thread Related Breakpoints
- Thread Stack Coverage
- Dynamic Task Performance Measurement
- PikeOS Specific Display of Real Time Trace Listing
- Statistical and Graphic Display of Thread Run Times
- Thread related Evaluation of Function Run Times
- PRACTICE Functions for OS Data
- PikeOS Related Pull-Down Menu

The TRACE32 System includes a configurable RTOS debugger to provide symbolic debugging in real time operating systems. Our software package contains a ready-to-run configuration for the PikeOS Real Time Operating System from SYSGO AG.


The PikeOS awareness provides easy access to task lists and other kernel information, generates performance analysis data and enables you to do a most effective debugging with the TRACE32 systems on targets running PikeOS.

RTOS Debugging in TRACE32 with PikeOS

Real Time, Non-Intrusive Display of PikeOS System Resources

The TRACE32 RTOS debugger for PikeOS provides display functions to show the system resources of PikeOS. All objects, such as tasks, threads, partitions etc. can be displayed and inspected. In addition, by using the processor's capability of reading the target

memory while the application is running, or by using the emulators dual-port memory (if available), the display of all these regions can be viewed non-intrusively in real time. The tables are updated permanently ("On The Fly"), without affecting the application at all.



Task list, thread list, resource partitions and detailed task window

Kernel and/or Application Debugging

Due to the fact, that TRACE32 is a hardware debugging tool, you are able to debug anything you want, including bootstrap code, initialization phase, interrupt routines, drivers, kernel, etc. TRACE32 includes a complete MMU support, providing mechanisms to inspect the target memory using virtual addresses or physical addresses and to show the translation tables.

Additionally, TRACE32 has a special MMU support for several address spaces, which allows you to debug several PikeOS applications (tasks) at once. An internal logic provides you with an easy access to all task memory spaces.

Debugging of a POSIX Personality

The RTOS Debugger for PikeOS contains an additional awareness for a POSIX Personality. It allows to debug

and view the POSIX threads and their states, running within a PikeOS task.

magic	name	state	prio	start	
0810F000	Mainthread	CV_WAIT	10	080206AC	_main
0810F800	Idlethread	RUNNING	0	08028EE8	idle_main

Threads running in a POSIX personality

Debugging of an ELinOS Personality

The RTOS Debugger for PikeOS contains an additional awareness for an ELinOS Personality, SYSGO's embed-

ded Linux distribution. It enables debugging the Linux kernel, kernel modules, user processes and libraries.

magic	command	#thr	state	spaceid	pids	
001362D0	swapper	11.	current	001A	0. 2. 3. 4.	
00C24000	init	-	sleeping	002E	1.	
00C27020	sh	-	sleeping	002D	14.	

magic	name	state	size	address
01828080	smalldriver	Live	539.	01828000
0182827C	bigdriver	Loading	11268.	01829000

Linux processes and kernel modules running in an ELinOS personality

Thread Related Breakpoints

Any breakpoint set in the TRACE32 debugger can be set dependent to a specific thread. This means, that the

breakpoint will then only halt, if hit by the specified thread. This allows thread related debugging even in shared code.

address	types	impl	task	
C:0016:080108E8	Program	SOFT	"Controller:Controller"	\Controller\Global\vm_init
C:0017:080100EC	Program	SOFT	"Calculator:Calculator"	\Calculator\calculator\p4_main

Breakpoint list with thread dependent breakpoints

Thread Context Display

The TRACE32 RTOS debugger provides an easy way to switch the current displayed context to another thread. Normally all register related windows (e.g. listing at current PC, local variables of function call stack) are dis-

played related to the actual context (i.e. current executed thread). You can switch to the context of another thread to see all this information at the time this thread was scheduled.

```

B::Frame /Task "Controller:Controller"
Up Down Args Locals Caller Task: "Controller:Controller" ▾
-000| p4_ipc(asn)
-001| vm_call_svc(asn)
-002| vm_cprintf(asn)
-003| p4_main()
  inport = ((id = 0), (id = 0), (id = 0))
  outport = ((id = 1), (id = 0), (id = 0))
  portconfig = (max_nb_messages = 32, max_msg_size = 256, direction = VM
  i = 3
  msgsize = 4
  counter = 0x60000000
  task_configured = (1, 0, 0)
  rc = VM_E_OK
  sleep_time = 3000000000
  fd = (i = (size = 0, pos = 0, type = VM_FILE_T_DIR, oflags = 0, vflags = 0
  taskid = (23, 0, 0)
  portname = "ContrIn2"
  my_uid = 2108416
  my_taskid = 22
  msgbuf = (23, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0,
    }
  }
  /* Show the number of calculations performed by each rem
  vm_cprintf("Calculations performed:");
-004| p4_entry()
  p4_main();
end of frame


```

Function call hierarchy of a specific thread

Thread Stack Coverage

In real time systems it is quite important to know, how much stack space each thread consumes. For this pur-

pose a special window shows the current and the maximum usage of each separate thread.




Thread stack coverage window

Dynamic Task Performance Measurement

While PikeOS is running, TRACE32 is capable of recurrently evaluating the current running thread and collecting the results. The percentage, each thread consumes of the system, is then

displayed graphically and updated permanently. The longer time you let the measurement run, the more exact are the results. This feature is available even without any hardware trace.



Performance measurement list

PikeOS Specific Display of Trace Listing


The data recorded in the real time trace buffer (if available) can be displayed and interpreted specific to the operating system. The thread switches are

displayed symbolically, either exclusively or in addition to other information.

Statistic Evaluation and Graphic Display of Thread Run Times

Out of the real time trace buffer (if available), the analyzer can calculate statistic tables of thread run times and thread switches. A graphical diagram

shows which thread was active at a specific time, giving a clear view of the behavior of the system.




Statistics and flow of threads

Thread Related Evaluation of Function Run Times

The statistic and graphic evaluation of function calls and function run times (if available) can be done dependant to the actual running thread. This is nec-

essary, if different threads call one single function at the same time, or if a thread switch occurs in between the function.



PRACTICE Functions for OS Data.


The support includes extended PRACTICE functions for PikeOS specific data, to be used in setup and test scripts. E.g. the function "task.con-

fig(magic)" returns the address of the so called magic value, which corresponds to the id of the current executing thread.


PikeOS related pull-down menu

Because the menu bar of the TRACE32 user interface can be fully customized, you can create a new pull down menu, including operating system specific commands. We deliver

PikeOS support with an example for such specific menus, which provides fast access to the PikeOS awareness features.



PikeOS specific menu items



TRACE32 with source/assembly window and opened PikeOS specific displays

Contact

International Representative

Argentina

Anacom Eletronica Ltda.
 Mr. Rafael Sorice
 Rua Nazareth, 807, Barcelona
 BR-09551-200 São Caetano do Sul, SP
 Phone: +55 11 3422 4200
 FAX: +55 11 3422 4242
 EMAIL: rsorice@anacom.com.br

Australia

Embedded Logic Solutions P/L
 Mr. Ramzi Kattan
 Suite 2, Level 3
 144 Marsden Street
 Parramatta NSW 2150
 Phone: +61 2 9687 1880
 FAX: +61 2 9687 1881
 EMAIL: sales@emlogic.com.au

Austria

Lauterbach GmbH
 Altläufstr. 40
 D-85635 Höhenkirchen-Siegertsbrunn
 Phone: +49 8102 9876 0
 FAX: +49 8102 9876 999
 EMAIL: info@lauterbach.com

Belgium

Tritec Benelux B.V.
 Mr. Robbert de Voogt
 Stationspark 550
 NL-3364 DA Sliedrecht
 Phone: +31 184 41 41 31
 FAX: +31 184 42 36 11
 EMAIL: software@tritec.nl

Brazil

Anacom Eletronica Ltda.
 Mr. Rafael Sorice
 Rua Nazareth, 807, Barcelona
 BR-09551-200 São Caetano do Sul, SP
 Phone: +55 11 3422 4200
 FAX: +55 11 3422 4242
 EMAIL: rsorice@anacom.com.br

Canada

Lauterbach Inc.
 Mr. Udo Zoettler
 4 Mount Royal Ave.
 USA-Marlborough, MA 01752
 Phone: +1 508 303 6812
 FAX: +1 508 303 6813
 EMAIL: info_us@lauterbach.com

China Beijing

Lauterbach Technologies Co., Ltd
 Mr. Linglin He
 Beijing Office
 A3, South Lishi Road, Xicheng District
 Beijing 100037, P.R. China
 Phone: +86 10 68023502
 FAX: +86 10 68023523
 EMAIL: linglin.he@lauterbach.com

China Shenzhen

Lauterbach Technologies Co., Ltd
 1406/E Xihaimingzhu Building
 No. 1 Taoyuan Road, Nanshan District
 Shenzhen 518052, P.R. China
 Phone: +86 755 8621 0671
 FAX: +86 755 8621 0675
 EMAIL: emily.zhang@lauterbach.com

China Suzhou

Lauterbach Technologies Co., Ltd
 Mr. Linglin He
 Hengyu Square, Rm 709
 No. 188, Xinghai Street
 Suzhou, 215021 P.R. of China
 Phone: +86 512 6265 8030
 FAX: +86 512 6265 8032
 EMAIL: info_cn@lauterbach.com

Czech. Republic

Lauterbach GmbH
 Altläufstr. 40
 D-85635 Höhenkirchen-Siegertsbrunn
 Phone: +49 8102 9876 0
 FAX: +49 8102 9876 999
 EMAIL: info@lauterbach.com

Denmark

Nohau Danmark A/S
 Mr. Flemming Jensen
 Klausdalsbroej 493
 DK-2730 Herlev
 Phone: +45 44 52 16 50
 FAX: +45 44 52 26 55
 EMAIL: info@nohau.dk

Egypt

Wantech Egypt
 Mr. Wagih A. Nawara
 5 Shafik Ghale St., Suite 2
 Off Pyramids Road, Giza
 Cairo 12111
 Phone: +20 100 1251955
 FAX: +20 100 1250349
 EMAIL: sales@wantechnet.com

Finland

Nohau Solutions Finland
 Mr. Martti Viljainen
 Teknobulevardi 3-5
 FI-01531 Vantaa
 Phone: +358 40 546 1469
 FAX: +358 9 2517 8101
 EMAIL: sales@nohau.fi

France

Lauterbach S.A.R.L.
 Mr. Jean-Pierre Paradiso
 Europarc - Le Hameau B
 135 Chemin Des Bassins
 F-94035 Créteil Cedex
 Phone: +33 1 49 56 20 30
 FAX: +33 1 49 56 20 39
 EMAIL: info_fr@lauterbach.com

Germany

Lauterbach GmbH
 Altläufstr. 40
 D-85635 Höhenkirchen-Siegertsbrunn
 Phone: +49 8102 9876 0
 FAX: +49 8102 9876 999
 EMAIL: info@lauterbach.com

Germany North

Lauterbach GmbH
 Mr. Klaus Hommann
 Leonhardring 5
 D-31319 Sehnde
 Phone: +49 8102 9876 174
 FAX: +49 5138 6185 3
 EMAIL: klaus.hommann@lauterbach.com

Germany South

Lauterbach GmbH
 Andreas Grimm
 Altauflstr. 40
 D-85635 Höhenkirchen-Siegertsbrunn
 Phone: +49 8102 9876 190
 FAX: +49 8102 9876 187
 EMAIL: andreas.grimm@lauterbach.com

Greece

Lauterbach GmbH
 Altauflstr. 40
 D-85635 Höhenkirchen-Siegertsbrunn
 Phone: +49 8102 9876 0
 FAX: +49 8102 9876 999
 EMAIL: info@lauterbach.com

Hungary

Lauterbach GmbH
 Altauflstr. 40
 D-85635 Höhenkirchen-Siegertsbrunn
 Phone: +49 8102 9876 0
 FAX: +49 8102 9876 999
 EMAIL: info@lauterbach.com

India-Bangalore

Electro Systems Associates Pvt. Ltd.
 Mr. G. V. Gurunathan
 S-606, World Trade Center
 Mallewaram West, No.26/1, Dr. Rajkumar
 Road
 India - Bangalore 560055
 Phone: +91 80 67648888
 FAX: +91 80 23475615
 EMAIL: Trace32sales@esaindia.com

India-Chennai

Electro Systems Associates Pvt. Ltd.
 Mr. D. Kannan
 No.109 /59A , Ground Floor
 IV Avenue, Ashok Nagar
 India - Chennai - 600 083 Tamilnadu
 Phone: +91 044-24715750
 FAX: ++91 44 24715750
 EMAIL: chennai@esaindia.com

India-Delhi

Electro Systems Associates Pvt. Ltd.
 Mr. R.K. Bhandari
 No. 705, 7th Floor, Laxmi Deep
 Shivajinagar
 India - Delhi - 110 092
 Phone: +91 11-22549351
 FAX:
 EMAIL: delhi@esaindia.com

India-Hyderabad

Electro Systems Associates Pvt. Ltd.
 Mr. C.V.M. Sri Ram Murthy
 Shop No. 14, "Global Enclave"
 Bhagyanagar Colony, Kukatpally
 India - Hyderabad 500 072
 Phone: +91 40-23063346
 FAX: +91 40-23063346
 EMAIL: hyderabad@esaindia.com

India-Pune

Electro Systems Associates Pvt. Ltd.
 Mr. R K Bhandari
 Shriram Complex,1126/1, Model Colony
 Shivajinagar
 India - Pune - 411 016
 Phone: +91 20 - 30462035 / 25663
 FAX: +91 20-25677202
 EMAIL: pune@esaindia.com

Ireland

Lauterbach Ltd.
 Mr. Barry Lock
 11 Basepoint Enterprise Centre
 Stroudley Road
 Basingstoke, Hants RG24 8UP
 Phone: +44-1256-333-690
 FAX: +44-1256-336-661
 EMAIL: info_uk@lauterbach.com

Israel

itec Ltd.
 Mr. Mauri Gottlieb
 P.O.Box 10002
 IL-Tel Aviv 61100
 Phone: +972 3 6491202
 FAX: +972 3 6497661
 EMAIL: general@itec.co.il

Italy

Lauterbach Srl
 Mr. Maurizio Menegotto
 Via Enzo Ferrieri 12
 I-20153 Milano
 Phone: +39 02 45490282
 FAX: +39 02 45490428
 EMAIL: info_it@lauterbach.com

Japan

Lauterbach Japan, Ltd.
 Mr. Kenji Furukawa
 3-8-8 Shinyokohama
 Kouhoku-ku, Nisso 16th Building
 Yokohama-shi, Japan 222-0033
 Phone: +81 45 477 4511
 FAX: +81 45 477 4519
 EMAIL: info@lauterbach.co.jp

Luxembourg

Tritec Benelux B.V.
 Mr. Robbert de Voogt
 Stationspark 550
 NL-3364 DA Sliedrecht
 Phone: +31 184 41 41 31
 FAX: +31 184 42 36 11
 EMAIL: software@tritec.nl

Malaysia

Flash Technology
 Mr. Teo Kian Hoeck
 No 61 # 04-15 Kaki Bukit Av 1
 Shun Li Industrial Park
 SGP-Singapore 417943
 Phone: +65 6749 6168
 FAX: +65 6749 6138
 EMAIL: teokh@flashtech.com.sg

Mexico

Lauterbach Inc.
 Mr. Udo Zoettler
 4 Mount Royal Ave.
 USA-Marlborough, MA 01752
 Phone: +1 508 303 6812
 FAX: +1 508 303 6813
 EMAIL: info_us@lauterbach.com

Netherlands

Trice Benelux B.V.
 Mr. Robbert de Voogt
 Stationspark 550
 NL-3364 DA Sliedrecht
 Phone: +31 184 41 41 31
 FAX: +31 184 42 36 11
 EMAIL: software@tritec.nl

New Zealand

Embedded Logic Solutions P/L
 Mr. Ramzi Kattan
 Suite 2, Level 3
 144 Marsden Street
 Parramatta NSW 2150
 Phone: +61 2 9687 1880
 FAX: +61 2 9687 1881
 EMAIL: sales@emlogic.com.au

Norway

Nohau Solutions AB
 Mr. Jörgen Nilsson
 Derbyvägen 4
 SE-21235 Malmö
 Phone: +46 40 592 206
 FAX: +46-40 592 229
 EMAIL: sales@nohau.se

Poland

QUANTUM Sp. z o.o.
 Mr. Aleksander Bil
 ul. Jeleniogorska 6
 54-056 Wrocław
 Phone: +48 71 362 6356
 FAX: +48 71 362 6357
 EMAIL: info@quantum.com.pl

Portugal

Captura Electronica,SCCL
 Mr. Juan Martinez
 c/Duero, 40
 E-08031 Barcelona
 Phone: +34 93 429 5730
 FAX: +34 93 407 0778
 EMAIL: info@captura-el.com

Romania

Lauterbach GmbH
 Altauferstr. 40
 D-85635 Höhenkirchen-Siegertsbrunn
 Phone: +49 8102 9876 0
 FAX: +49 8102 9876 999
 EMAIL: info@lauterbach.com

Russia

RTSoft
 Mr. Alexey Isaev
 Nikitinskaya 3
 RUS-105037 Moscow
 Phone: +7 495 742 6828
 FAX: +7 495 742 6829
 EMAIL: sales@rtsoft.msk.ru

Singapore

Flash Technology
 Mr. Teo Kian Hock
 No 61, # 04-15 Kaki Bukit Av 1
 Shun Li Industrial Park
 SGP-Singapore 417943
 Phone: +65 6749 6168
 FAX: +65 6749 6138
 EMAIL: teokh@flashtech.com.sg

South Korea, Pangyo

MDS Technology Co.,Ltd.
 Mr. Sangheon Lee
 3FL, Hancom Tower
 49, Daewangpangyo-ro 644, Bundang-gu
 Seongnam-si, Gyeonggi-do, 463-400, ROK
 Phone: +82-31-627-3000
 FAX: +82-31-627-3100
 EMAIL: trace32@mdstec.com

Spain

Captura Electronica,SCCL
 Mr. Juan Martinez
 c/Duero, 40
 E-08031 Barcelona
 Phone: +34 93 429 5730
 FAX: +34 93 407 0778
 EMAIL: info@captura-el.com

Sweden

Nohau Solutions AB
 Mr. Jörgen Nilsson
 Derbyvägen 4
 SE-21235 Malmö
 Phone: +46 40 592 206
 FAX: +46 40 592 229
 EMAIL: sales@nohau.se

Switzerland

JDT Jberg DatenTechnik
 Mr. Andreas Jberg
 Zimmereistrasse 2
 CH-5734 Reinach AG
 Phone: +41 62 7710 886
 FAX:
 EMAIL: Andreas.Jberg@jdt.ch

Taiwan

Superlink Technology Corp.
 Mr. Sulin Huang
 3F-8,No.77,Sec.1,Xintaiwu Rd.,Xizhi District,
 New Taipei City 22101, Taiwan, R.O.C.
 Phone: +886 2 26983456
 FAX: +886 2 26983535
 EMAIL: info.stc@superlink.com.tw

Tunisia

Lauterbach Consulting S.A.R.L.
 Mr. Khaled Jmal
 Route El Ain Km 3.5
 TN-3062 Sfax
 Phone: +216-74611730
 FAX: +216-74611723
 EMAIL: info_tn@lauterbach.com

Turkey-1

Tektronik Muh. ve Tic. A.S.
 Mr. Hakan Yavuz
 CyberPlaza B-Blok, 702B
 Bilkent
 06800 Ankara
 Phone: +90 312 437 3000
 FAX: +90 312 437 1616
 EMAIL: info@tektronik.com.tr

Turkey-2

G3TEK Embedded Technologies Ltd.
 Mr. Celal Aygun
 İlkyerlesim Mah. 445.
 Sok. No: 48
 06370 Batıket/Ankara
 Phone: +90 312 3324769
 FAX: +90 312 3324769
 EMAIL: info@g3tek.com

UK

Lauterbach Ltd.
 Mr. Barry Lock
 11 Basepoint Enterprise Centre
 Stroudley Rd
 Basingstoke, Hants RG24 8UP
 Phone: +44 1256 333 690
 FAX: +44 1256 350 301
 EMAIL: info_uk@lauterbach.com

USA East

Lauterbach Inc.
 Mr. Udo Zoettler
 4 Mount Royal Ave.
 USA-Marlborough, MA 01752
 Phone: +1 508 303 6812
 FAX: +1 508 303 6813
 EMAIL: info_us@lauterbach.com

USA West

Lauterbach Inc.
 Mr. Bob Kupyn
 1111 Main Street, Suite 620
 USA-Vancouver, WA, 98660
 Phone: +1 503 524 2222
 FAX: +1 503 524 2223
 EMAIL: bob.kupyn@lauterbach.com

Additional Information

<http://www.lauterbach.com>

Lauterbach GmbH

Altaufstr. 40
D-85635 Höhenkirchen-Siegertsbrunn
Tel. ++49 8102 9876-0 FAX -999
info@lauterbach.com
http://www.lauterbach.de

Lauterbach Inc.

4 Mount Royal Ave.
Marlboro MA 01752
Phone (508) 303 6812 FAX (508) 303 6813
info_us@lauterbach.com
http://www.us.lauterbach.com

Lauterbach Ltd.

11 Basepoint Enterprise Ctre Stroudley Road
Basingsfoke, Hants RG24 8UP
Phone ++44-1256-333-690 FAX -661
info_uk@lauterbach.com
http://www.lauterbach.co.uk

Lauterbach S.A.R.L.

135 Chemin Des Bassins
F-94035 Créteil Cedex
Phone ++33-149-562-030
FAX ++33-149-562-039
info_fr@lauterbach.com
http://www.lauterbach.fr

Lauterbach Japan, Ltd.

3-9-5 Shiryokohama Kouhoku-ku
Yokohama-shi Japan 222-0033
Phone ++81-45-477-4511 FAX -4519
info_j@lauterbach.com
http://www.lauterbach.co.jp

Lauterbach s.r.l.

Lauterbach s.r.l.
Via Enzo Ferrieri 12
I-20153 Milano
Phone ++39 02 45490282
FAX ++39 02 45490428
info_it@lauterbach.it
http://www.lauterbach.it

Suzhou Lauterbach Consulting Co.,Ltd.

Room 1605, Xing Hai International Square
No.200, Xing Hai Street
Suzhou, 215021 PR of China
Phone: 0086-512 6265 8030
FAX: 0086-512 6265 8032
info_cn@lauterbach.cn
http://www.lauterbach.cn

Disclaimer

The information presented is intended to give overview information only.
Changes and technical enhancements or modifications can be made without notice.