

TRACE32[®] Manuals



www.lauterbach.com

LEADING through Technology

LAUTERBACH
DEVELOPMENT TOOLS 

Copyright (C) 1988 - 24.10.11 Lauterbach GmbH

Structure and Contents of the Documentation

This chapter describes the structure of the TRACE32 Documentation - printed as well as online.

Since the development of the TRACE32 software is always in progress, the online version of the manuals will always be more up to date than the printed version. The first pages of the printed documentation contains the edition date.

The release history in the online documentation lists always the latest changes in the TRACE32 software. When you get a new version of the TRACE32 software, please always check the [Release history](#) first.

Online Documentation

The most current version of the TRACE32 documentation is always online.

There are several ways to get access to this documentation:

1. If the TRACE32 software is already running you can use the **Help** command in the main menu bar.
2. On the TRACE32 software CD and in your TRACE32 system path you can find a directory `\PDF`. This directory contains the complete TRACE32 documentation in .pdf format.

Open `directory.pdf` to get the table of contents for the complete TRACE32 documentation.

Documentation on how to use the online help can be found in the [Help System](#) documentation.

The documentation is automatically filtered by your currently used hardware configuration. By this filter, the whole documentation is reduced to the relevant part for you. If you want to change the filter, take a look at the command [HELP.FILTER](#).

When using the RTOS/multi task functionality, you have to enable the RTOS documentation:

```
::HELP.FILTER.ADD rtos*           Enable all available RTOS documentation
::HELP.FILTER.ADD rtoslinux      Enable only the documentation for Linux
                                 RTOS Debugger
```

In-Circuit Debugger TRACE32-ICD

TRACE32-ICD includes all debuggers based on an on-chip debug interface (e.g. JTAG, BDM, OCDS ...) as well as ROM monitor solutions. LAUTERBACH provides also a trace extension for most debuggers (TRACE32-ICT).

TRACE32-ICD comes with the booklet "**ICD Introduction**" (icd_introduction.pdf), that provides all information about installing TRACE32-ICD on your host system plus a tutorial that should make you familiar with the main features of TRACE32-ICD.

For more information on the features of TRACE32-ICD refer to the following parts of the online help:

"Target Guides ICD"	This part provides all CPU specific information for your TRACE32-ICD, chiefly how to set up the debugger for your target. Here you will also find all extra features that are supported for your CPU.
"General Reference Guide"	This part provides an alphabetical list of all debugger commands. All commands that are not available for TRACE32-ICD are marked with (E) - TRACE32-ICE only or (F) -TRACE32-FIRE only.
"TRACE32 Online Help" (main.pdf)	All TRACE32 development tools share the common user interface TRACE32-PowerView. This part describes the basic functions of the user interface (command structure, online help, editing and managing files, printer operations etc.)
"IDE Reference Guide" (ide_ref.pdf)	This part provides an alphabetical list of all operating system commands.
"PRACTICE Script Language User's Guide" (practice_user.pdf)	The TRACE32 batch language PRACTICE is mainly used to perform automatic setups, to automate test sequences or to store the system settings for later recall. This part describes the basic structure and features of the PRACTICE programming language.
"PRACTICE Script Language Reference Guide" (practice_ref.pdf)	This part provides an alphabetical list of all PRACTICE instructions.
"ICD Extensions"	Refer to this part, if you want to use the TPU debugger or the PCP debugger.
"RTOS Debuggers"	Refer to this part if you want to use the TRACE32-Multitask Debugger. Use the command HELP.FILTER.ADD rtos* to see all RTOS documentation.
"Front-end"	Refer to this part, if you want to run TRACE32-ICD from a 3rd party user interface.
"TRACE32 Installation Guide" (installation.pdf)	This part is the general Installation Guide for all TRACE32 development tools.

TRACE32-ICE comes with 4 binders which provide documentation support for all its capabilities.

TRACE32-ICE is divided into two major functional units: the emulator and the analyzer.

- The emulator-part of TRACE32-ICE is responsible for carrying out debugging functions, for managing breakpoints, for displaying memory and high-level-language structures and for code coverage.
- The analyzer-part of TRACE32-ICE is responsible for displaying and managing the trace buffer, for programming the analyzer trigger unit to perform selective tracing and to carry out complex trigger sequences, for statistic functions and performance analyses.

The following list will give you an idea of the contents of each manual.

"ICE User's Guide" (ice_user.pdf)	This parts makes you familiar with the concept and the main features of the emulator-part of TRACE32-ICE.
"ICE Targets"	This part provides all CPU specific information for your TRACE32-ICE, chiefly how to set up TRACE32-ICE for your target. Here you will also find all extra features that are supported for your CPU.
"General Reference Guide"	This part provides an alphabetical list of all commands for the emulator-part of TRACE32-ICE. All commands that are not available for TRACE32-ICE are marked with (B) - TRACE32-ICD only or (F) -TRACE32-FIRE only.
"Analyzer User's Guide" (analyzer_user.pdf)	This part makes you familiar with the concept and the main features of the analyzer-part of TRACE32-ICE.
"Analyzer Trigger Unit Programming Guide" (analyzer_prog.pdf)	This part makes you familiar with the concept of the trigger programming language. It contains examples for trigger programs and alphabetical lists of all actions and input events.
"TRACE32 Online Help" (main.pdf)	All TRACE32 development tools share the common user interface TRACE32-PowerView. This part describes the basic functions of the user interface (command structure, online help, editing and managing files, printer operations etc.).
"IDE Reference Guide" (ide_ref.pdf)	This part provides an alphabetical list of all operating system commands.
"PRACTICE Script Language User's Guide" (practice_user.pdf)	The TRACE32 batch language PRACTICE is mainly used to perform automatic setups, to automate test sequences or to store the system settings for later recall. This part describes the basic structure and features of the PRACTICE programming language.
"PRACTICE Script Language Reference Guide" (practice_ref.pdf)	This part provides an alphabetical list of all PRACTICE instructions.

<p>"ICD Extensions"</p>	<p>Refer to this part, if you want to use the TPU debugger.</p>
<p>"RTOS Debuggers"</p>	<p>Refer to this part if you want to use the TRACE32-Multitask Debugger. Use the command HELP.FILTER.ADD rtos* to see all RTOS documentation.</p>
<p>"Front-end"</p>	<p>Refer to this part, if you want to run TRACE32-ICE from a 3rd party user interface.</p>
<p>"TRACE32 Installation Guide" (installation.pdf)</p>	<p>This part is the general Installation Guide for all TRACE32 development tools.</p>
<p>"ICE Port Analyzer User's Guide" (port_user.pdf)</p>	<p>Your TRACE32-ICE can be enhanced by a port analyzer to trace additional CPU lines. A description of the Port Analyzer and its features is provided in the "ICE Port Analyzer User's Guide" (port_user.pdf).</p>
<p>"Timing Analyzer"</p>	<p>The Timing Analyzer provides timing and state analysis, a pattern generator and a serial line tester. A description of the Timing Analyzer and its features is provided in the "Timing Analyzer User's Guide" (time_user.pdf), the "Timing Analyzer Reference Guide" (time_ref.pdf) and the "Timing Analyzer Trigger Unit Programming Guide" (time_prog.pdf).</p>

TRACE32-FIRE comes with 4 binders which provide documentation support for all its capabilities.

The following list will give you an idea of the contents of each manual.

"FIRE User's Guide" (fire_user.pdf)	This part makes you familiar with the concept and the main features of TRACE32-FIRE.
"FIRE Targets"	This part provides all CPU specific information for your TRACE32-FIRE, chiefly how to set up TRACE32-FIRE for your target. Here you will also find all extra features that are supported for your CPU.
"General Reference Guide"	This part provides an alphabetical list of all commands for debugging and trace with TRACE32-FIRE. All commands that are not available for TRACE32-FIRE are marked with (B) - TRACE32-ICD only or (E) - TRACE32-ICE only.
"Analyzer Trigger Unit Programming Guide" (analyzer_prog.pdf)	This part makes you familiar with the concept of the trigger programming language. It contains examples for trigger programs and alphabetical lists of all actions and input events.
"TRACE32 Online Help" (main.pdf)	All TRACE32 development tools share the common user interface TRACE32-PowerView. This part describes the basic functions of the user interface (command structure, online help, editing and managing files, printer operations etc.).
"IDE Reference Guide" (ide_ref.pdf)	This part provides an alphabetical list of all operating system commands.
"PRACTICE Script Language User's Guide" (practice_user.pdf)	The TRACE32 batch language PRACTICE is mainly used to perform automatic setups, to automate test sequences or to store the system settings for later recall. This part describes the basic structure and features of the PRACTICE programming language.
"PRACTICE Script Language Reference Guide" (practice_ref.pdf)	This part provides an alphabetical list of all PRACTICE instructions.
"ICD Extensions"	Refer to this part, if you want to use the TPU debugger and PCP debugger.
"RTOS Debuggers"	Refer to this part if you want to use the TRACE32-Multitask Debugger. Use the command HELP.FILTER.ADD rtos* to see all RTOS documentation.
"Front-end"	Refer to this part, if you want to run TRACE32-FIRE from a 3rd party user interface.

"TRACE32 Installation Guide" (installation.pdf)	This part is the general Installation Guide for all TRACE32 development tools.
"FIRE Port Analyzer User's Guide" (fireport_user.pdf)	Your TRACE32-FIRE can be enhanced by a port analyzer to trace additional CPU lines. A description of the Port Analyzer and its features is provided in the "FIRE Port Analyzer User's Guide" (fireport_user.pdf).

TRACE32 Online Help	(main.pdf)
TRACE32 Directory	(directory.pdf)
TRACE32 Index.....	(index.pdf)
TRACE32 Getting Started	
ICD In-Circuit Debugger Getting Started	
ICD Introduction	(icd_introduction.pdf)
ICD Quick Installation	(icd_quick_installation.pdf)
ICD Tutorial	(icd_tutorial.pdf)
TRACE32 Documents	
IDE User Interface	
IDE User's Guide	(ide_user.pdf)
IDE Reference Guide.....	(ide_ref.pdf)
IDE Functions	(ide_func.pdf)
PRACTICE Script Language	
PRACTICE Script Language User's Guide.....	(practice_user.pdf)
PRACTICE Script Language Reference Guide	(practice_ref.pdf)
Application Notes for PRACTICE	
Converter from GEL to PRACTICE	(converter_gel.pdf)
General Commands and Functions	
General Commands Reference Guide A	(general_ref_a.pdf)
General Commands Reference Guide B	(general_ref_b.pdf)
General Commands Reference Guide C	(general_ref_c.pdf)
General Commands Reference Guide D	(general_ref_d.pdf)
General Commands Reference Guide E	(general_ref_e.pdf)
General Commands Reference Guide F.....	(general_ref_f.pdf)
General Commands Reference Guide G	(general_ref_g.pdf)
General Commands Reference Guide H	(general_ref_h.pdf)
General Commands Reference Guide I.....	(general_ref_i.pdf)
General Commands Reference Guide J.....	(general_ref_j.pdf)

General Commands Reference Guide K	(general_ref_k.pdf)
General Commands Reference Guide L.....	(general_ref_l.pdf)
General Commands Reference Guide M.....	(general_ref_m.pdf)
General Commands Reference Guide N	(general_ref_n.pdf)
General Commands Reference Guide O	(general_ref_o.pdf)
General Commands Reference Guide P	(general_ref_p.pdf)
General Commands Reference Guide Q	(general_ref_q.pdf)
General Commands Reference Guide R	(general_ref_r.pdf)
General Commands Reference Guide S	(general_ref_s.pdf)
General Commands Reference Guide T.....	(general_ref_t.pdf)
General Commands Reference Guide U	(general_ref_u.pdf)
General Commands Reference Guide V	(general_ref_v.pdf)
General Commands Reference Guide W	(general_ref_w.pdf)
General Commands Reference Guide X	(general_ref_x.pdf)
General Commands Reference Guide Y	(general_ref_y.pdf)
General Commands Reference Guide Z.....	(general_ref_z.pdf)
General Functions.....	(general_func.pdf)

High-Level Language Debugging

Application Note C++ Debugging	(app_cpp_debugging.pdf)
--------------------------------------	-------------------------

FLASH Programming

NOR FLASH Programming User's Guide	(norflash.pdf)
NAND FLASH Programming User's Guide.....	(nandflash.pdf)
Serial FLASH Programming User's Guide	(serialflash.pdf)
eMMC FLASH Programming User's Guide	(emmcflash.pdf)
List of Supported FLASH Devices	(flashlist.pdf)

Application Notes for FLASH

How to Write your own FLASH Algorithm	(flash_app_own_algorithm.pdf)
Tips to Solve NOR FLASH Programming Problems	(flash_diagnosis.pdf)

Boundary Scan

Boundary Scan User's Guide.....	(boundary_scan.pdf)
---------------------------------	---------------------

Peripheral Files

Peripheral Files Programming Commands.....	(per_prog.pdf)
Converter SPIRIT XML to PER Commands.....	(converter_spiritxml.pdf)

Analyzer System

Analyzer Programming

- [Analyzer Trigger Unit Programming Guide \(analyzer_prog.pdf\)](#)
- [Analyzer Programming Dialog\(analyzer_dialog.pdf\)](#)
- [Analyzer User's Guide\(analyzer_user.pdf\)](#)
- [ICE Performance Analyzer User's Guide \(performance_user.pdf\)](#)
- [Protocol Analyzer Application Note \(protocol_app.pdf\)](#)

System Trace

RTOS Debugger

- [RTOS Debugger for AMX.....\(rtos_amx.pdf\)](#)
- [RTOS Debugger for ARTK..... \(rtos_artk.pdf\)](#)
- [RTOS Debugger for ARTX-166.....\(rtos_rtxartx166.pdf\)](#)
- [RTOS Debugger for Chorus Classic.....\(rtos_chorus_classic.pdf\)](#)
- [RTOS Debugger for Chorus Micro..... \(rtos_chorus_micro.pdf\)](#)
- [RTOS Debugger for Cmicro \(rtos_cmicro.pdf\)](#)
- [RTOS Debugger for CMX.....\(rtos_cmx.pdf\)](#)
- [RTOS Debugger for CMX-TINY+ \(rtos_cmx_tiny.pdf\)](#)
- [RTOS Debugger for DSP/BIOS.....\(rtos_bios.pdf\)](#)
- [RTOS Debugger for eCos \(rtos_ecos.pdf\)](#)
- [RTOS Debugger for embOS \(rtos_embos.pdf\)](#)
- [RTOS Debugger for FAMOS..... \(rtos_famos.pdf\)](#)
- [RTOS Debugger for FreeRTOS\(rtos_freertos.pdf\)](#)
- [RTOS Debugger for HI7000\(rtos_hi7000.pdf\)](#)
- [RTOS Debugger for Linux - Run Mode.....\(rtos_linux_run.pdf\)](#)
- [RTOS Debugger for Linux - Stop Mode..... \(rtos_linux_stop.pdf\)](#)
- [RTOS Debugger for MicroC/OS-II\(rtos_ucos.pdf\)](#)
- [RTOS Debugger for MicroC/OS-III\(rtos_ucos3.pdf\)](#)
- [RTOS Debugger for LynxOS \(rtos_lynx.pdf\)](#)
- [RTOS Debugger for MQX.....\(rtos_mqx.pdf\)](#)
- [RTOS Debugger for MTOS-UX \(rtos_mtos.pdf\)](#)
- [RTOS Debugger for NetBSD \(rtos_netbsd.pdf\)](#)
- [RTOS Debugger for NORTi..... \(rtos_norti.pdf\)](#)
- [RTOS Debugger for Nucleus PLUS \(rtos_nucleus.pdf\)](#)

RTOS Debugger for OKL4	(rtos_okl4.pdf)
RTOS Debugger for OS-9	(rtos_os9.pdf)
RTOS Debugger for OS21	(rtos_os21.pdf)
RTOS Debugger for OSE Classic.....	(rtos_ose_classic.pdf)
RTOS Debugger for OSE Delta	(rtos_ose_delta.pdf)
RTOS Debugger for OSE Epsilon	(rtos_ose_epsilon.pdf)
RTOS Debugger for OSEck	(rtos_oseck.pdf)
RTOS Debugger for OSEK/ORTI	(rtos_orti.pdf)
RTOS Debugger for PrKERNEL	(rtos_prkernel.pdf)
RTOS Debugger for pSOS+	(rtos_psos.pdf)
RTOS Debugger for PXROS	(rtos_pxros.pdf)
RTOS Debugger for QNX - Run Mode	(rtos_qnx_run.pdf)
RTOS Debugger for QNX - Stop Mode	(rtos_qnx_stop.pdf)
RTOS Debugger for RealTimeCraft	(rtos_realtimcraft.pdf)
RTOS Debugger for RTEMS	(rtos_rtems.pdf)
RTOS Debugger for RTOS/7700	(rtos_rt7700.pdf)
RTOS Debugger for RTX-ARM	(rtos_rtxarm.pdf)
RTOS Debugger for RTX166.....	(rtos_rtx166.pdf)
RTOS Debugger for RTX166 tiny	(rtos_rtx166_tiny.pdf)
RTOS Debugger for RTX51.....	(rtos_rtx51.pdf)
RTOS Debugger for RTX51 tiny	(rtos_rtx51_tiny.pdf)
RTOS Debugger for RTXC	(rtos_rtxc.pdf)
RTOS Debugger for RTXC Quadros	(rtos_quadros.pdf)
RTOS Debugger for Rubus OS	(rtos_rubus.pdf)
RTOS Debugger for SMX	(rtos_smx.pdf)
RTOS Debugger for Symbian OS EKA1	(rtos_epoc.pdf)
RTOS Debugger for Symbian OS EKA2 - Run Mode	(rtos_symb2_run.pdf)
RTOS Debugger for Symbian OS EKA2 - Stop Mode	(rtos_symb2_stop.pdf)
RTOS Debugger for SYS/BIOS.....	(rtos_sysbios.pdf)
RTOS Debugger for ThreadX	(rtos_threadx.pdf)
RTOS Debugger for VDK	(rtos_vdk.pdf)
RTOS Debugger for VRTX32/68K.....	(rtos_vrtx.pdf)
RTOS Debugger for VRTX80	(rtos_vrtx_80.pdf)

RTOS Debugger for VRTXmc/68K	(rtos_vrtx_mc.pdf)
RTOS Debugger for VRTXsa	(rtos_vrtx_sa.pdf)
RTOS Debugger for Vx Works	(rtos_vxworks.pdf)
RTOS Debugger for Windows CE	(rtos_windows_ce.pdf)
RTOS Debugger for Windows CE6	(rtos_windows_ce6.pdf)
RTOS Debugger for ZeOS	(rtos_zeos.pdf)
RTOS Debugger for uClinux.....	(rtos_uclinux.pdf)
RTOS Debugger for uiPLUS	(rtos_uiplus.pdf)
VM Debugging	
VM Debugger Dalvik.....	(vmdalvik.pdf)
Application Note for Android	
TRACE32 JTAG Bridge for Android	(android_jtag_bridge.pdf)
Virtual Targets	
Virtual Targets User's Guide	(virtual_targets.pdf)
Target Server	
GDB Target Server	
TRACE32 GDB Target Server	(monitor_gdb.pdf)
EPOC Target Server	(monitor_epoc.pdf)
OSE Target Server.....	(monitor_ose.pdf)
TRACE32 pdebug Target Server for ARM.....	(monitor_pdebug_arm.pdf)
Windows Native Process Debugger	(windows_debugger.pdf)
3rd Party Tool Integrations	
Coupling for Eclipse	(int_eclipse.pdf)
Integration of ChipScope Analyzer.....	(int_chipscope.pdf)
Integration for CodeBlocks	(int_codeblock.pdf)
Integration for CodeWright.....	(int_codewright.pdf)
Integration for EasyCase	(int_easycase.pdf)
Integration for eXDI2 on Windows CE Platform Builder.....	(int_exdi2.pdf)
Integration with LabView	(int_labview.pdf)
Integration with OSE Illuminator.....	(int_ose.pdf)
Integration for Rhapsody in MicroC	(int_rhapsody_mc.pdf)
Integration for Rhapsody in C/C++	(int_rhapsody_cpp.pdf)
Integration for Tornado I, agentless	(int_tornado.pdf)

Integration for Tornado I, WDB-agent (int_tornado_agent.pdf)

Integration for Visual Basic Interface..... (int_visualbasic.pdf)

Integration for X-Tools and X32 (int_xtools.pdf)

TRACE32 Instruction Set Simulators

API for TRACE32 Instruction Set Simulator (simulator_api.pdf)

Library for Peripheral Simulation (simulator_api_lib.pdf)

Simulator for ARM and XSCALE..... (simulator_arm.pdf)

Simulator for HC08/MSC08..... (simulator_hc08.pdf)

Simulator for HC12/MCS12..... (simulator_hc12.pdf)

Simulator 68K/ColdFire.....(simulator_68k.pdf)

Simulator C166/ST10.....(simulator_c166.pdf)

Simulator x186.....(simulator_x186.pdf)

Simulator for H8/300, H8/300H and H8S..... (simulator_h8.pdf)

Simulator SuperH (simulator_sh.pdf)

Simulator for MIPS (simulator_mips.pdf)

Simulator PowerPC (simulator_ppc.pdf)

Simulator for TriCore (simulator_tricore.pdf)

Simulator Z80+ (simulator_z80.pdf)

ICD In-Circuit Debugger

ICD Debugger User's Guide (debugger_user.pdf)

ICD Extensions

EPROM/FLASH Simulator.....(eprom_simulator.pdf)

TPU Debugger (tpu.pdf)

ICD Target Guides

78K

78K0R/RL78 Debugger..... (debugger_78k.pdf)

Andes

Andes Debugger..... (debugger_andes.pdf)

APS

APS Debugger (debugger_aps.pdf)

ARC

ARC Debugger..... (debugger_arc.pdf)

ARM/CORTEX/XSCALE

ARM and XSCALE Debugger	(debugger_arm.pdf)
ARM and XSCALE Monitor	(monitor_arm.pdf)
Cortex-M Debugger	(debugger_cortexm.pdf)
ARM-ETM Trace.....	(trace_arm_etm.pdf)
ARM-ETM Training	(training_arm_etm.pdf)
ARM-ETM Programming Dialog	(trace_arm_etm_dialog.pdf)
ARM-ETM RTS User's Guide	(rts_user.pdf)
RAM Trace Port	(trace_rtp.pdf)
ARM Application Notes	
ARM JTAG Interface Specifications	(arm_app_jtag.pdf)
Setup the Debugger for a CoreSight System	(arm_app_coresight.pdf)
ARM Application Note for MXC Chips.....	(arm_app_mxc.pdf)
AVR32	
AVR32 Debugger and NEXUS Trace.....	(debugger_avr32.pdf)
Beyond	
Blackfin	
Blackfin Debugger.....	(debugger_blackfin.pdf)
C166 Family	
XC2000/XC16x/C166CBC Debugger	(debugger_166cbc.pdf)
XC16x Application Notes	
Application Note OCDS Debug Cable	(tricore_app_ocds.pdf)
C166 Monitor.....	(monitor_c166.pdf)
C166 Family Trace.....	(trace_c166.pdf)
CEVA-Oak/Teak/TeakLite	
CEVA-Oak/Teak/TeakLite Debugger	(debugger_oak.pdf)
CEVA-X	
CEVA-X Debugger	(debugger_cevax.pdf)
CPU32 and ColdFire	
CPU32 and ColdFire Debugger and Trace	(debugger_68k.pdf)
DSP56K	
DSP56K Debugger.....	(debugger_56000.pdf)
eTPU	
eTPU Debugger	(debugger_etpu.pdf)

H8S

H8S/23x9 Debugger..... (debugger_h8s.pdf)

H8S and H8/300H Monitor..... (monitor_h8.pdf)

M32R

M32R Debugger and Trace(debugger_m32r.pdf)

M8051EW

M8051EW Debugger..... (debugger_m8051ew.pdf)

8051XC

R8051XC Debugger (debugger_r8051xc.pdf)

MAC71xx/72xx

MCS08

MCS08 Debugger..... (debugger_hc08.pdf)

MCS12

MCS12 Debugger..... (debugger_hc12.pdf)

MicroBlaze

MicroBlaze Debugger and Real-Time Trace(debugger_microblaze.pdf)

MicroBlaze Application Note

Connecting to MicroBlaze Targets for Debug and Trace(app_microblaze.pdf)

MIPS

MIPS Debugger and Trace..... (debugger_mips.pdf)

MMDSP

MMDSP Debugger(debugger_mmdsp.pdf)

MMDSP NEXUS Debugger and Trace.....(nexus_mmdsp.pdf)

MMDSP Application Note

Debugging NMF Applications with TRACE32.....(app_mmdsp.pdf)

MSP430

MSP430 Debugger..... (debugger_msp430.pdf)

M-Core

M-Core Debugger(debugger_mcore.pdf)

NEC VR

NIOS

NIOS II Debugger and Trace..... (debugger_nios.pdf)

NIOS II Application Note

NIOS II Instantiating the Off-chip Trace Logic.....	(app_nios.pdf)
NS32000	
NS32000 Monitor	(monitor_ns32000.pdf)
PPC400/PPC440	
PPC400/PPC440 Debugger and Trace.....	(debugger_ppc400.pdf)
PPC400/PPC440 Application Note	
Debugging Embedded PPC Cores in Xilinx FPGAs.....	(app_xilinx_ppc400.pdf)
MPC500/PQ	
MPC5xx/8xx Debugger and Trace.....	(debugger_ppc.pdf)
MPC56x NEXUS Debugger and Trace	(nexus_mpc5xx.pdf)
MPC55xx/MPC56xx	
MPC55xx/MPC56xx Debugger.....	(debugger_mpc5500.pdf)
PQII, MPC5200, MPC603/7xx, MPC74xx	
PPC600 Family Debugger	(debugger_ppc600.pdf)
PQII Trace.....	(trace_mpc82xx.pdf)
PQIII	
PQIII Debugger	(debugger_ppcpq3.pdf)
PWRficient	
PWRficient Debugger.....	(debugger_pwr.pdf)
RX Debugger	
RX Debugger.....	(debugger_rx.pdf)
StarCore	
StarCore Debugger and Trace	(debugger_starcore.pdf)
StarCore Application Note	
StarCore Application Note for MXC Chips.....	(starcore_mxc_app.pdf)
SuperH	
SH2, SH3 and SH4 Debugger	(debugger_sh4.pdf)
SH2 Monitor	(monitor_sh.pdf)
TI DSPs	
TMS320C2X Debugger	(debugger_c2000.pdf)
TMS320C5X Debugger	(debugger_c5500.pdf)
TMS320C6X Debugger	(debugger_c6000.pdf)
TriCore	

TriCore Debugger and Trace	(debugger_tricore.pdf)
TriCore Application Notes	
Application Note OCDS Debug Cable	(tricore_app_ocds.pdf)
TriCore On-Chip FLASH Programming	(tricore_app_flash.pdf)
TriCore Monitor	(monitor_tricore.pdf)
PCP Debugger Reference	(debugger_pcp.pdf)
PCP Debugger - Legacy	(debugger_pcp_legacy.pdf)
V850	
V850 Debugger and Trace	(debugger_v850.pdf)
x86	
x86 Debugger	(debugger_x86.pdf)
x186	
x186 Monitor	(monitor_x186.pdf)
x196	
x196 Monitor	(monitor_196.pdf)
x386 and x486	
x386 and x486 Monitor	(monitor_x386.pdf)
XA51	
XA51 Monitor	(monitor_xa51.pdf)
XC800	
XC800 Debugger	(debugger_xc800.pdf)
XC800 Application Notes	
Application Note OCDS Debug Cable	(tricore_app_ocds.pdf)
XTENSA	
XTENSA Debugger	(debugger_xtensa.pdf)
Z80	
Z80 Monitor	(monitor_z80.pdf)
ZSP	
ZSP Debugger	(debugger_zsp.pdf)
ICE In-Circuit Emulator	
ICE User's Guide	(ice_user.pdf)
ICE Port Analyzer User's Guide	(port_user.pdf)
ICE Memory Modules	(ice_memory_modules.pdf)

ICE Target Guides

ICE Emulator for 68000	(ice_68000.pdf)
ICE Emulator for MC68000 and MC6830X	(ice_68300.pdf)
ICE Emulator for MC68020/30	(ice_68020.pdf)
ICE Emulator for MC68040/60	(ice_68040.pdf)
ICE Emulator for MC6833X	(ice_68330.pdf)
ICE Emulator for Motorola 68360/349	(ice_68360.pdf)
ICE Emulator for 68HC05 and 68HC08	(ice_hc08.pdf)
ICE Emulator for 68HC11	(ice_hc11.pdf)
ICE Emulator for MELPS 7700	(ice_melps.pdf)
ICE Emulator for C166/ST10	(ice_c166.pdf)

C166/ST10 Application Note

Update C167-E2 to C167-E3	(app_ice166.pdf)
ICE Emulator for the 80186 and 80196	(ice_x186.pdf)
ICE Emulator for INTEL 196K Family	(ice_196k.pdf)
ICE Emulator for 386/486	(ice_i386.pdf)
ICE Emulator for 8051	(ice_51.pdf)
ICE Emulator for 90CL301	(ice_90301.pdf)
ICE Emulator for Hitachi H8/300 and H8/500	(ice_h8.pdf)
ICE Emulator for PowerPC	(ice_mpc8xx.pdf)
ICE Emulator for Z80 and Z180	(ice_z80.pdf)

Timing Analyzer

Timing Analyzer User's Guide	(time_user.pdf)
Timing Analyzer Reference Guide	(time_ref.pdf)
Timing Analyzer Trigger Unit Programming Guide	(time_prog.pdf)

FIRE In-Circuit Emulator

FIRE User's Guide	(fire_user.pdf)
-------------------------	-----------------

FIRE Training

Training FIRE Basics	(training_fire.pdf)
Training FIRE Analyzer	(training_fire_analyzer.pdf)
Training FIRE PortAnalyzer	(training_fire_port.pdf)
FIRE Port Analyzer User's Guide	(fireport_user.pdf)

FIRE Target Guides

FIRE Emulator for HC12/MCS12.....	(fire_hc12.pdf)
FIRE Emulator for C166 Family	
FIRE Emulator for C166 Family	(fire_c166.pdf)
FIRE Emulator for C166S V2 Family	(fire_xc166.pdf)
FIRE Emulator for C166 Cell-Based-Core	(fire_166cbc.pdf)
FIRE Emulator for H8S and H8/300H	(fire_h8s.pdf)
FIRE Emulator for SH2.....	(fire_sh2.pdf)
CombiProbe User's Guide.....	(combiprobe_user.pdf)
PowerProbe	
PowerProbe User's Guide	(powerprobe_user.pdf)
PowerProbe/Port Analyzer Reference Guide.....	(powerprobe_ref.pdf)
PowerProbe SOC User's Guide.....	(powerprobe_soc.pdf)
PowerProbe Trigger Unit Programming Guide	(powerprobe_prog.pdf)
Protocol Analyzer Application Note	(protocol_app.pdf)
FlexRay Protocol Analyzer	(flexray_app.pdf)
LIN Bus Protocol Analyzer	(linbus_app.pdf)
IProbe	
IProbe User's Guide	(iprobe_user.pdf)
PowerIntegrator	
PowerIntegrator User's Guide.....	(powerintegrator_user.pdf)
PowerIntegrator Programming Guide	(powerintegrator_prog.pdf)
PowerIntegrator Application Notes	
PowerIntegrator State Trace Application Note.....	(powerintegrator_app_state.pdf)
PowerIntegrator Trace DisConfig Application Note.....	(powerintegrator_app_dc.pdf)
PowerIntegrator Setup Application Note	(powerintegrator_app_setup.pdf)
Protocol Analyzer Application Note	(protocol_app.pdf)
DigRF Protocol Analyzer	(digrf_app.pdf)
FlexRay Protocol Analyzer	(flexray_app.pdf)
LIN Bus Protocol Analyzer	(linbus_app.pdf)
EPROM/FLASH Simulator.....	(eprom_simulator.pdf)
Stimuli Generator	
Stimuli Generator User's Guide	(stg_user.pdf)
Stimuli Generator Reference Guide.....	(stg_ref.pdf)

Stimuli Generator Functions	(stg_func.pdf)
Trigger Probe	
Trigger Probe User's Guide.....	(tp_user.pdf)
Misc	
Error Messages	(error.pdf)
API for Remote Control and JTAG Access	(api_remote.pdf)
API for Auxiliary Processing Unit.....	(api_apu.pdf)
API for GDB Debugger.....	(api_gdb.pdf)
Command List	(commandlist.pdf)
TRACE32 Training	
Debugger Training	
Debugger Basics - Training.....	(training_debugger.pdf)
Advanced Debugging Topics	
Training JTAG Interface.....	(training_jtag.pdf)
Training Real-time Trace	(training_trace.pdf)
TRAINING ARM-ETM	
ARM-ETM Training	(training_arm_etm.pdf)
TRAINING NEXUS	
Training ICE Emulator	
Training ICE Basics.....	(training_ice.pdf)
Training ICE Analyzer	(training_ice_analyzer.pdf)
Training FIRE Emulator	
Training FIRE Basics	(training_fire.pdf)
Training FIRE Analyzer	(training_fire_analyzer.pdf)
Training FIRE PortAnalyzer.....	(training_fire_port.pdf)
Training Power Probe	
Training Power Probe	(training_pp.pdf)
Training HLL Debugging	(training_hll.pdf)
Training PRACTICE.....	(training_practice.pdf)
Training Menu.....	(training_menu.pdf)
Training RTOS	
Training Linux Debugging.....	(training_rtos_linux.pdf)
Training Simulator and Demo Software	(demo.pdf)

[TRACE32 Installation Guide..... \(installation.pdf\)](#)

[T32Start \(app_t32start.pdf\)](#)

TRACE32 Technical Support

[Support Addresses \(support.pdf\)](#)

[Release History \(release.pdf\)](#)

[Software Updates \(updates.pdf\)](#)